



Lift the handset OR

Press **1**.

Dial the number OR

Press a **Speed Call** key OR

Press **9** OR

Dial the prefix for external calls (e.g. 9) and the number.

Answer a Call

Lift the handset OR

Press **1**, and begin speaking.

End a Call

Press **1** OR

Replace the handset.
